



INSTRUCTIONS

1. Mix 3 scoops of perfectcast, one scoop of water and one paint pot together in disposable container.
2. Pour the mixture into the bottom bead mold. Make sure you pour enough material into the mold so that it barely overflows the cavities.
3. Place a rod in each of the grooves. The casting material should be higher than the halfway point of the rod, but not covering it. Too little material and the holes will not be large enough to thread the bead string, and too much material will not allow removal of the rods.

WARNING: Do not pour excess casting material into the drain or toilet bowl. Dispose of excess casting material in the garbage. If you use a spoon for mixing, wash the spoon immediately after pouring the material.

4. Wait 1 hour for the beads to dry.
5. Remove the rods from the mold. Clean and save the rods for more casts.
6. Turn the bead mold over and tap it on the table until all the beads drop out.
7. Sand the beads until flat and smooth. Clean the dust out of the grooves. (You will sand the edges of the beads after they are glued.)
8. Match the bead halves to insure that the holes on each side match. If they don't match, turn one of the bead halves around. Paint a small amount of glue on both halves of the beads and stick them together. Let the beads dry for at least a half hour. Repeat until all beads are glued together. Be careful not to paint glue in the bead groove. (Make sure you clean the paint brush.)
9. After the glue has dried, sand the edges until smooth.
10. You can paint a gloss coat on the beads for a shiny finish or just leave them with a matt finish. (Make sure you clean the paint brush.)
11. Measure the length of the bracelet or necklace and add 6 inches before cutting. Thread the beads with bead cord. Tie a knot in the cord and cut off the excess.

Items Needed: Disposable mixing cup, spoon or mixing stick.

Items Included: Casting material, mold tray, flex cord, rods, paints, paint brush, measuring scoop and instruction sheet.